

MiniFinder® Rex

User manual



Thank you!

Thank you for purchasing your MiniFinder Rex, we are absolutely sure you made the right choice. Rex is full of smart features to help you monitor, protect and locate the animal at all hours of the day.

MiniFinder Rex primarily includes the ability to track in real time, but it's also possible to view position history and thereby examine the hunting dog's movements afterwards. The device is completely waterproof and can be used in all weather conditions.

Before you start using your Rex, please read this manual in it's entirety.

Package contents

1. MiniFinder Rex
2. USB-C charging cable
3. Wall charger

1



2



3



LED lights

Green LED

3 sec

3 sec

Single blink = *Searching for mobile network*

Double blink = *Connected to mobile network*

Steady light = *Fully charged*

Red LED

1 sec

Single blink = *Connected to Bluetooth*

Steady light = *Charging*

Blue LED

3 sec

3 sec

Slow blink = *Searching for GPS signal*

Single blink = *Connected to satellite*

Product management

Before using your Rex for the first time, it's recommended to charge the unit for 3 hours. While charging, the red LED will blink slowly every 3 seconds. Once the battery is fully charged, the red LED will stay solid.

To **turn on** the unit, press the On/Off button until it vibrated and the LED starts blinking.

To **turn off** the unit, hold the On/Off button for 10 seconds until the LED shuts off.

Note!

1. During the shutdown process, the light will start flashing and continue to flash for 90 seconds until the device is powered off.
2. Rex is not compatible with a smart charger.

Download MiniFinder Hunter


Introducing MiniFinder Hunter, the latest online community created exclusively for hunters across the globe. With our innovative app, you can now easily monitor your dog's location and seamlessly communicate with your hunting team during your hunting session!

Following your hunting session, you can quickly access the post-hunt history. Gain insight into where your dog has been by the re-play function and re-live the best moments from the hunt. Our app has answers to many of your hunt questions, and it's free!

Get started today by downloading the MiniFinder Hunter app from either the Apple App Store or Google Play. Simply search for "MiniFinder Hunter" and join our community of hunters worldwide.



If you read this user manual on your mobile phone, please click on the link below to download.



Apple: <https://apple.co/jfyds>



Android: <https://play.co/jfyds>



App overview

Once you have downloaded the app, the initial step is to create an account. Simply input your email address and a password to get started. Once logged in, you will be presented with an app overview, which is displayed on the right-hand side of your screen.


Within the overview, you will find a plethora of functions that will enhance your hunting experience, making it both more efficient and secure. In this manual, we will delve into some of the features offered by the app.



Menu




To access the quick menu, simply click on the orange MiniFinder button. This will allow you to quickly access key features such as the Tag function, Hunting grounds, and Teams.

Additionally, there is another menu located in the top left-hand corner of the screen. By clicking on this menu you access your profile, devices, licenses, subscription, and help function.



Profile settings

To modify or add information to your profile, simply click on the manu located in the top left corner of the screen and select "Profile". This will take you to the Profile settings where you can easily make changes to your personal information, update your profile picture or change your password.




Add a new device

This applies only to new devices. To access a device that someone else has, see the instructions on how to Share location.

To add a new device to your account, start your MiniFinder and connect it to a charger. Make sure Bluetooth is turned on in your mobile phone and that you are close to your MiniFinder during the registration process.

Go to the menu and select Devices. From there, tap Add new device and choose the device model you want to add. The app will now search for nearby devices and you will be given a suggested device. Check that the last four digits shown on the screen (#XXXX) match the last four digits of the IMEI number on the back of your MiniFinder.


If the numbers match, tap Yes. If not, choose to add the device manually. You can do this by entering the IMEI code yourself or by scanning the barcode on the packaging. Finally, choose a name for your MiniFinder and tap Add device.



Device list

To access a list of devices that have been added to your account, select Devices from the menu. This will display a comprehensive list of your registered devices. By clicking on a specific device from the list, a drop-down menu will appear.


Within the drop-down menu, you will find two options. The first is Show on map, which will take you to the map where you can view your dog's real-time position. The second option is Profile settings, which we will explore in the next chapter.



Device profile settings

The Device profile settings section allows you to input specific information regarding your dog, such as its breed, date of birth, and weight. Furthermore, you can choose a different dog icon or upload a profile picture.

Once you have completed these steps, simply click Save to save your changes.



Device panel

The Device Panel gives you a quick overview of your dog and access to several of the device’s key features. To open the panel, tap your dog’s profile on the map.


Here you can view your dog’s speed, distance and BPM (barks per minute). Swipe the panel upwards to access additional options, including update interval, call, vibration, LED light, sound signal and Find Me. The Find Me feature uses Bluetooth to help you locate the device when you are nearby.

The panel can be moved up or down depending on how much information you want to display while keeping the map visible. Further down, you will also find View Profile and Settings, where you can access additional information about your dog and view previous location history.



Device settings

Clicking on Settings in the Device panel will take you to a page where you can adjust various settings to further enhance your hunting experience. From here you can share the dog’s position, choose trail color, set the sensitivity of the bark detector and much more.




Add contacts

To add contacts, go to the team icon located in the app footer. Find the Contacts icon and select it. This section is located in the middle of the panel and gives you access to your contact list. To add a new contact, click on the plus sign next to the search function.

Now you can add a new contact in three different ways:

1. Easily import your existing contacts from your phone to MiniFinder Hunter.
2. If you have the person's email address, enter it in the designated field.
3. If the person is nearby, you can easily scan the person's QR code, which they can find in their profile. The QR code must be scanned using the camera function directly in the MiniFinder Hunter app.




Hunting grounds

To create a hunting ground, open Hunting Ground from the quick menu. Mark the area you want to use as your hunting ground by placing points on the map and connecting them.


Give your hunting ground a name and select a color before saving. Once the hunting ground has been created, you can easily adjust its boundaries afterwards. Press and hold a point on the boundary, then drag it to a new position on the map. This allows you to change the shape of the hunting ground without having to redraw the entire area.

Once you have created a hunting ground, you can continue by creating a team. To invite other users, you can use the QR code or enter a user code, which can be generated in the same place as the QR code.




Tags

To access the Tag function, click on the quick menu and select it. Move the crosshair to the location where you want to place the tag. You will be presented with a variety of different tags to choose from. Once you have selected the tag you want to place on the map, add a tag label and additional details to the tag if desired. Click on Save and the tag will appear on the map.



Share position

To share your own position or your dog’s position, open your contact list again. Look up the person you want to share your position with and press their name to open their profile. Once you’re in the profile view, you have the option to easily share both your own and your dog’s position with others.




Hunting team

To create a new team, go to the Team icon in the footer of the app and tap Create New Team. Enter a team name and then add the hunting ground the team will use. You can create a new hunting ground, select an existing one or import a hunting ground.

Once the team has been created, you can invite team members and start planning upcoming hunts.


If you are a member of several teams, you can easily select the team you want to focus on for the upcoming hunt. When you select a team, you will be taken directly to the selected hunting ground on the map.



Create hunt


To create a hunting event, access the calendar symbol in the footer and select Plan hunt. Here, you can choose the hunting ground, start and end date, and a description of the event. Invitations will be sent to the selected hunters, and the event will automatically appear on the calendar.

You will receive notifications when the invited hunters accept or decline your invitaion.



Guides in app

If you prefer a hands-on approach to learning, we've included some helpful guides within the app. To access them, simply click on the menu icon in the top left corner of the screen and select Help. You'll find a variety of guides that will walk you through the basic features and functions of the app. Welcome to the MiniFinder Hunter community and happy hunting!



Cancellation of subscription

If you have decided to terminate your subscription, follow these simple steps to complete the process:

1. Open the application and navigate to Subscription.
2. Click on Cancel subscription.
3. After you have canceled the subscription, MiniFinder's finance department will confirm the cancellation via email.

Technical specification

Dimensions	80 mm x 40 mm x 30 mm
Weight	100g
System	MiniFinder Firmware MFLPC™
Network	4G, LTE-M, CAT-M1
Battery	Rechargeable, 2500mAh
Interface	USB-C
GSM band	900MHz, 1800MHz
Power source	1A ~ 1.5A
Bluetooth	BLE 5.0
G-sensor	Yes
Battery life	Up to 100h
Charging voltage	5V - 2A (10W)
Memory	16M (Flash memory)
Waterproof	Yes, IP67
LED	3 indicating GPS and voltage
Guidance LED light	Yes, 200m range
Buttons	1 button (on/off)
Speaker	Yes
Microphone	Yes
Vibration	Yes
High sensitivity GPS/GLONASS receiver	Yes
WiFi	2.4GHz, 802.11 b/g/n
Necklace	2.54 cm
Warranty	3 years

Safety statement

This equipment has been tested to comply with safety certificate in accordance with the specifications of the standard: EN 60950-1: 2006 + A12: 2011.

Important safety instructions

- Please read these instructions.
- Please keep these instructions.
- Please follow all instructions.
- Please take heed of all warnings.
- Do not open the unit. Substances in this product and / or the battery can damage the environment, and / or human health if handled improperly.
- Do not tamper with your MiniFinder®.
- Do not use abrasive cleaners to clean your MiniFinder®.
- Do not put your MiniFinder® in a dishwasher, washing machine or dryer.
- Do not expose your MiniFinder® to extremely high or low temperatures.
- Do not bring your MiniFinder® into a sauna or a steam bath.
- Do not leave your MiniFinder® in the direct sunlight for a long time.
- Do not place your MiniFinder® near an open flame.
- Do not throw your MiniFinder® in a fire. The battery can explode!
- Do not attempt to disassemble a MiniFinder®, it contains non-replaceable components
- Never let children under 3 years of age play with MiniFinder®. Small components can be a choking hazard for them.

Built-in battery precautions

- Do not attempt to open the built-in battery by force.
- Do not try to replace your MiniFinder® battery. It is built in and can not be replaced.
- Please charge the battery in accordance with the instructions provided with this guide.
- Use only CE certified charger to charge the battery. NOTE: DO NOT use a so-called "Fast Charger".
- Please charge your MiniFinder® with the help of a certified computer, hub or power supply.

Recycling information

The symbol on the product or its packaging means that this product must be disposed of separately from ordinary household wastes at its end of life. Please be aware that this is your responsibility to dispose the electronic equipment at recycling centers to help conserve natural resources.